Maintenance and care 4

4-1. Maintenance and care 264

Cleaning and protecting the vehicle exterior 264

Cleaning and protecting the vehicle interior 266

4-2. Maintenance 269

Maintenance requirements 269

General maintenance 271

Emission inspection and maintenance (I/M) programs 274

4-3. Do-it-yourself maintenance 275

Do-it-yourself service precautions 275

Hood 279

Positioning the jack 280

Engine compartment 282

Tires 297

Tire inflation pressure 305

Wheels 309

Air conditioning filter 311

Electronic key battery 313

Checking and replacing fuses 315

Headlight aim (vehicles with discharge headlights) 324

Light bulbs 325